POLYETHYLENE BIDIRECTIONAL CELLS DUAL RELEASE GRAPE GUARD 46 x 33 cm 7 gr

TECHNICAL SHEET



TRADE MARK PROTEKU



DESCRIPTION

This polyethylene bidirectional cells dual release grape guard is formed by two sheets of simple paper with Polyetylene (PE) and a third sheet with Kraft white paper. The grape guard is heat-sealed and contains the active ingredient of Sodium Metabisulfite (Na2S2O5), which reacts to humidity (over 70%) to create SO2 (Sulfur Dioxide). The SO2 inhibits and prevents the development of Botrytis cinerea Pers. in grapes during cold storage and transportation.

THECNICAL SPECS & ERROR MARGIN					
Width	460	mm	± 5 mm		
Length	330	mm	± 5 mm		
Cells	0		-		
Área	1518	cm ²	-		
Sodium metabisulfite content in slow release	6,0	gr	± 0,2 gr		
Sodium metabisulfite content in fast release	1,0	gr	± 0,2 gr		
Sodium metabisulfite total (both stages)	7,0	gr	± 0,4 gr		
Pad Weight	28,9	gr	± 0,5gr		
Box Weight	12,4	kg	± 0,5 kg		

 $\underline{\text{Note:}}$ Different dosages and sizes can be provided as required.

PACKAGING				
Units per box	400			
Boxes per pallets	72			
Units per pallet	28.800			
CLIENT CODE				

PALLETIZING				
Length	1,48	m		
Width	1,09	m		
Heigth	2,44	m		
Quantity	72			
Net weigth per pallet	890	kg		
Gross weigth per pallet	910	kg		
BOX SIZE				
Dimensions	47x34x285			

CONTAINER				
Conteiner of 40'	8 pallets			
Conteiner of 40' High Cube	16 pallets			

RAW MATERIALS	Units of measure for the granulometry of sodium metabisulfite					
Tyler size	+20	+30	+48	+65	+100	-100
Fast release	0,27	0,58	1,33	5,85	10,9	81,07
Slow release	7,8	35,7	22,2	17,8	8,90	7,6

TYPE SHEETS	Weight gr	Origin	Grammage	Dimensions	Printing	N° CAS
Polyethylene simple paper	8,3	Spain-Italy	40/15	46x33	SI	9002-88-3
Polyethylene simple paper	8,3	Spain-Italy	40/15	46x33	NO	9002-88-4
Kraft white paper	5,3	Austria-Italy	35	46x33	NO	9003-07-0

PROTEKU INTERNAL CODE	P172

OBSERVATIONS

The Proteku SO2 sheets must be stored in a cool dry area and avoid contact with sun.

When the packing of grapes is finished every day, the SO2 sheets should be placed back in the original bag and sealed. If stored according to instructions the Proteku SO2 sheets have a shelf life of at least 2 years. After this time the SO2 sheets must be tested or sent to our Laboratory.

The disposal of our Proteku sheets should be according to official regulations of each country and according to MSDS certificate.